



**Allens**  
Music Centre

Hit the right note

**A 2 0 0 0**

*From Broadway*



## SPECIFICATIONS

Keyboard		Upper keyboard :61 Lower keyboard:61 Pedal keyboard:25	<b>Soft Touch™ by Fatar</b>
	After Touch(Sensitivity)	Upper keyboard Lower keyboard	
	After Touch (Pitch)	Upper keyboard Lower keyboard	
	Sensitivity	16 levels	
	Split	Lead voice 1/2 Pedal keyboard 1/2	
Registration	Pedal	Mono/Poly	
	Registration Memory	M, 1-16, D	
	Registration Bank	A, B, C, D	
	Registration Group	Multiple files (>=20) 、 power saved, USB disk	
Voice	Registration Shift	Shift / User	
	Voice Sections	Upper keyboard 1/2 Lead voice 1/2 lower keyboard 1/2 Pedal keyboard 1/2	
	Preset voice	370	
	Voice control	Volume Pad Transpose Tune Octave Attack Decay Release Delay vibrato rate、 Vibrato depth、 Vibrato delay Resonance Cut.Freq	
	Slide	Lead Voice 1 / 2	
	Slide setting	On/Off、 Time	
EFFECT	Keyboard Percussion	14 drum group; 2 set of user custom drum set	
	Sustain	Upper keyboard Voice Lower keyboard Voice Pedal keyboard Voice	
	Revber Type	Room1、 Room2、 Room3、 Hall1、 Hall2、 Stage1、 Stage2、 Plate	
	The adjustable parameters	Dealy、 Mas.level、 Time、 Feedback	
	Chorus Type	Chorus1、 Chorus2、 Chorus3、 Chorus4、 FeedBACK、 Flanger、 ShortDelay、 FB Delay	
	The adjustable parameters	Mas.level、 Feedback、 Rate、 Depth	
RHYTHM	IFX EFFECT	WAH Distortion EQ Chorus/flanger/phaser/tremolo/rotary	
	Preset rhythm type	191	
	Rhythm control	Fade Start/Stop Intro Ending Variation1/2 ManiA/B Synchro Tempo	
	Rhythm part	Drum1, Drum2, Chord1, Chord2, Pad, Phrase1, Phrase2	
	Voice selection	√	
	Auto bass chord	Turn off Finger Auto Bass	
	Chord memory	Lower keyboard、 Pedal keyboard	
SEQ	Chord chorus	Off、 1、 2、 3、 4 type	
	Rhythm sequence design	SEQ1、 SEQ2	
PAD	Tone sequence design	Automatic switch	
	Supported types	MP3、 MIDI	
EQ	The adjustable parameters	Volume	
Master Transpose	The adjustable parameters	125Hz、 250Hz、 500Hz、 1kHz、 2kHz、 4kHz、 8kHz	
	Keyboard	Transpose	
FOOTSWITCH	MIDI Play	USB MIDI transpose	
	Left footswitch	Rhythm Start/Stop Variation Ending Sustain	
	Right footswitch	Switch to registration memory	
	Expression Pedal	Control the strength	
Joy Stick	Pitch Pedal	Pitch pedal	
	Shake	Pitch <b>Touchless Controller: 18 options</b>	
	Up	Modulation	
MIDI Control	Down	Cut Off	
	MIDI In /MIDI Out	On/Off	
USB DISK	Playback options	Play Stop Pause Rew Ff Customize the play Record Registration/MIDI/Audio Speed 50%-200%	
	Other features	Playback settings、 selection of folder, file type、 rename、 delete the file、 new folder, file order, file copy	
Basic Set	Initialization	√	
	Display	Display style	
	LCD brightness	√	
Others	LCD Display	800xRGBx480 <b>Extra Large Colour LCD screen</b>	
	Interface	Phones, Mic, Line In / Out +Bal. Out, USB to Host, Midi In/Out, USB Charger	
	<b>Speakers and Amplifier</b>	<b>30W x 2, 25w x 2, 20w x 2 &amp; 10w x 2 speakers (8-speakers total)</b>	
	<b>Organ Dimensions</b>	<b>1,251 x 600 x 1,042mm</b>	
	Included Accessories	Bench, Owners Guide, USB memory stick (inc bonus registrations)	



## Official U.K. Dealer

Market Gates Shopping Centre, Great Yarmouth, Norfolk, NR20 2AX

T: 01493 842887 / 850172

W: [www.allensmusiccentre.co.uk](http://www.allensmusiccentre.co.uk)