



Allens
Music Centre

Hit the right note

RS760

Ringway



SPECIFICATIONS

Keyboard		Upper keyboard: 49 Lower keyboard:61 Pedal keyboard:25
	After Touch(Sensitivity)	Upper keyboard Lower keyboard
	After Touch (Pitch)	Upper keyboard Lower keyboard
	Sensitivity	16 levels
	Split	Lead voice 1/2 Pedal keyboard 1/2
Registration	Pedal	Mono/Poly
	Registration Memory	M, 1-16, D
	Registration Bank	A, B, C, D
	Registration Group	Multiple files (>=20) 、 power saved, USB disk
Voice	Registration Shift	Shift / User
	Voice Sections	Upper keyboard 1/2 Lead voice 1/2 lower keyboard 1/2 Pedal keyboard 1/2
	Preset voice	365
	Voice control	Volume Pad Transpose Tune Octave Attack Decay Release Delay vibrato rate、 Vibrato depth、 Vibrato delay Resonance Cut.Freq
	Slide	Lead Voice 1 / 2
	Slide setting	On/Off、 Time
	Keyboard Percussion	14 drum group; 2 set of user custom drum set
EFFECT	Sustain	Upper keyboard Voice Lower keyboard Voice Pedal keyboard Voice
	Revber Type	Room1、 Room2、 Room3、 Hall1、 Hall2、 Stage1、 Stage2、 Plate
	The adjustable parameters	Dealy、 Mas.level、 Time、 Feedback
	Chorus Type	Chorus1、 Chorus2、 Chorus3、 Chorus4、 FeedBACK、 Flanger、 ShortDelay、 FB Delay
	The adjustable parameters	Mas.level、 Feedback、 Rate、 Depth
RHYTHM	IFX EFFECT	WAH Distortion EQ Chorus/flanger/phaser/tremolo/rotary
	Preset rhythm type	191
	Rhythm control	Fade Start/Stop Intro Ending Variation1/2 ManiA/B Synchro Tempo
	Rhythm part	Drum1, Drum2, Chord1, Chord2, Pad, Phrase1, Phrase2
	Voice selection	√
	Auto bass chord	Turn off Finger Auto Bass
	Chord memory	Lower keyboard、 Pedal keyboard
SEQ	Chord chorus	Off、 1、 2、 3、 4 type
	Rhythm sequence design	SEQ1、 SEQ2
PAD	Tone sequence design	Automatic switch
	Supported types	MP3、 MIDI
EQ	The adjustable parameters	Volume
	The adjustable parameters	125Hz、 250Hz、 500Hz、 1kHz、 2kHz、 4kHz、 8kHz
Master Transpose	Keyboard	Transpose
	MIDI Play	USB MIDI transpose
FOOTSWITCH	Left footswitch	Rhythm Start/Stop Variation Ending Sustain
	Right footswitch	Switch to registration memory
	Expression Pedal	Varies Volume / Adds expression
Pitch Bend		
	Wheel	Pitch Up or Down
MIDI Control	MIDI In /MIDI Out	On/Off
USB DISK	Playback options	Play Stop Pause Rew Ff Customize the play Record Registration/MIDI/Audio Speed 50%-200%
	Other features	Playback settings、 selection of folder, file type、 rename、 delete the file、 new folder, file order, file copy
Basic Set	Initialization	√
	Display	Display style
	LCD brightness	√
Others	LCD Display	Full colour display
	Interface	Headphones, USB to Host, USB charger, Line Out (L/R), Line In (Stereo), Mic, Mic Vol.
	The power amplifier	40W x 2 • 50W x 2
	Speaker	Bass: 2 x 167mm x 68.5mm • Treble: 2 x 52mm x 52mm
	Piano size	W: 1,040mm • D: 480mm • H: 940mm (1,140mm including music rest)
	Included Accessories	Bench, Owners Guide, USB memory stick (inc bonus registrations)



Official U.K. Dealer

Market Gates Shopping Centre, Great Yarmouth, Norfolk, NR20 2AX

T: 01493 842887 / 850172

W: www.allensmusiccentre.co.uk